

USO DELL'AEROGRAFO A DOPPIA AZIONE

Riempire il serbatoio con colorante liquido specifico per aerografo.

Per capire il corretto funzionamento dell'aerografo si consiglia di esercitarsi su un foglio di carta variando il flusso dell'aria e la distanza dal piano di lavoro.

MANUTENZIONE DELL'AEROGRAFO

Svuotare completamente il serbatoio e lavare con alcol etilico.

Per la pulizia degli organi interni riempire il serbatoio con alcol etilico, otturare l'aerografo mettendo un dito sull'ugello e premere il grilletto. L'aria, circolando in direzione inversa, pulisce gli elementi che si trovano fra l'ugello e il serbatoio ed elimina eventuali residui. Ripetete l'operazione più volte. Vaporizzare per alcuni secondi l'alcol su carta per controllare che l'aeropenna sia completamente pulita, se si dovessero presentare residui di colore ripetere l'intera operazione.

La pulizia è molto importante e deve essere eseguita alla perfezione al termine di ogni utilizzo.

COMPONENTI AEROGRAFO



- | | |
|----|---|
| 1 | Coroncina
Cod. RICNEEDLECAP |
| 2 | Test per ugello Ø 0,3 mm
Cod. RICNOZZLECAP1 |
| 3 | Ugello - Ø 0,3 mm
Cod. RICTIPNOZZLE1 |
| 8 | Molla
Cod. RICNEEDLESPRING |
| 9 | Serbatoi
13cc / 5cc / 2cc |
| 10 | Ago - per ugello Ø 0,3 mm
Cod. RICNEEDLE1 |
| 11 | Vite di serraggio ago
Cod. RICNEESTOPSCREW |
| 23 | Dado del connettore al tubo
Cod. RICAIRTUBESCREW |
| 24 | Portagomma
Cod. RICAIRTUBECLASP |

HOW TO USE OUR DOUBLE ACTION AIRBRUSH

Fill the cup with specific liquid colour for airbrush.

To understand how to use the airbrush we recommended to practice on a sheet of paper by varying the air flow and the distance from the working surface.

AIRBRUSH UPKEEPING

Empty the fluid cup and wash with ethyl alcohol.

To clean the internal parts fill the cup with ethyl alcohol, close the airbrush by putting a finger on the nozzle and press the tripper. Air will clean the elements that are placed between the nozzle and the cup and will remove any residual by circulating in the opposite direction. Repeat the process. Spray some alcohol on paper for a few seconds to make sure the airbrush is completely clean: if you find any residual colour repeat all the former steps. **Cleanliness is very important and must be perfectly performed after every use.**

AIRBRUSH COMPONENTS



- | | |
|----|---|
| 1 | Needle cover
Cod. RICNEEDLECAP |
| 2 | Cap for nozzle Ø 0,3 mm
Cod. RICNOZZLECAP1 |
| 3 | Nozzle - Ø 0,3 mm
Cod. RICTIPNOZZLE1 |
| 8 | Spring
Cod. RICNEEDLESPRING |
| 9 | Cups
13cc / 5cc / 2cc |
| 10 | Needle for nozzle Ø 0,3 mm
Cod. RICNEEDLE1 |
| 11 | Needle clamp screw
Cod. RICNEESTOPSCREW |
| 23 | Tube connector nut
Cod. RICAIRTUBESCREW |
| 24 | Hose connector
Cod. RICAIRTUBECLASP |