



Martellato


Flambé Pro

Professional Culinary Torch
Cannello Professionale

Turbo Flame

1300°C - 2400°F

BLU FLAME



Multifunctional kitchen torch

for pastry, gastronomy and cooking.

Ideal for caramelizing sugar and meringues, for gratinating, melting and heating.

Easy to use - Adjustable flame

Continuous flame button, Easily refillable

Gas not included

Cannello multifunzionale

per pasticceria, gastronomia e cucina.

ideale per caramellare zucchero e meringhe, per gratinare, scaldare e sciogliere.

Facile da usare - Fiamma regolabile

Pulsante fiamma continua, Facilmente ricaricabile

Gas non incluso

www.martellato.com

Goods imported by
Prodotto importato da
Martellato srl - via Rovigo, 1/B
Vigonza (PD) Italy
tel. +39 049 7800155
martellato@martellato.com


MADE IN CHINA

INSTRUCTIONS

IGNITION & EXTINGUISHING: 1) Turn the Gas Control Knob counterclockwise to release the gas flow valve. 2) Release the ON/OFF Switch by pushing the Switch upward. 3) Press and hold the Trigger to ignite the Culinary Torch. 4) Release the Trigger to extinguish the flame. **CONTINUOUS FLAME:** To keep the flame continuously lit, press down on the Continuous Flame Switch and release the Trigger (after unlocking and igniting the Culinary Torch). To extinguish the continuous flame, press down on the Trigger once more then release. **FLAME ADJUSTMENT:** Turn the Gas Control Knob counterclockwise to increase the flame strength or clockwise to decrease the flame strength. Turn the Knob clockwise completely will extinguish the flame. **REFILLING GAS TANK:** Turn off the continuous flame and release the Trigger. Make sure the flame is fully extinguished. Wait until the Culinary Torch has completely cooled down before refilling. Only refill in a well ventilated area, away from any open flame, inflammable materials, fire hazard or smoking. Room temperature should be above 16°C. Use only 100% purified clean Butane Gas. Avoid using Butane Gas that contains much impurity to block the injection valve. Hold the Culinary Torch upside down. Insert the Nozzle of the Butane Canister into the Torch Refilling Valve. Fill slowly and stop refilling once gas starts to overflow. Wait at least 3 minutes before using to allow the gas to stabilize and the excess surface gas to vaporize. Please note that during the first time use, the Gas Tank must be filled with Butane Gas completely until the gas starts to overflow. The air inside the empty Gas Tank must come out before you can secure a good ignition. **OVERFILL WILL CAUSE THE FLAME TO SPIT - WARNING: KEEP OUT OF THE REACH OF CHILDREN - EXTREMELY FLAMMABLE CONTENTS UNDER PRESSURE** Never store at temperature above 40°C (104°F) or expose to prolonged sunlight. Do not work in enclosed spaces holding combustible vapors, flammable liquids or explosive materials nor use near spark or open flame; maintain good ventilation. Do not puncture or incinerate. Assembly and adjustable made in the factory shall not be modified. It can be dangerous to try to modify the adjustment or the construction of the Torch, to dismantle some parts or to use components other than these recommended. Do not drop the Torch as the unit might be damaged and broken. Do not attempt to repair or use the Torch which shows any damage. In case of leakage, take the Torch to an open space with good ventilation away from spark or open flame. Until the Gas is empty and return the Torch to the distributor. Wear eye protection equipment. **FOLLOW REFILLING PROCEDURE TO AVOID SERIOUS ACCIDENT.** Ignite the Torch away from face, clothing and other combustible materials. Do not straight the flame to any person. Please note that butane flame may barely visible in certain lighting conditions. The Torch Nozzle will become extremely hot during and after operation. Please protect yourself from accidental burns. Ensure the flame is extinguished after each use. Allow the Torch to cool down before storing.

ISTRUZIONI

ACCENSIONE E SPEGNIMENTO: 1) Ruotate in senso antiorario la Manopola di Controllo del Gas per aprire la valvola del gas. 2) Spingete l'interruttore ON/OFF verso l'alto. 3) Tenete premuto il Grilletto per accendere il Cannello Professionale. 4) Rilasciate il Grilletto per spegnere la fiamma. **FIAMMA CONTINUA:** Perché la fiamma rimanga accesa senza tenere premuto il Grilletto, (dopo aver sbloccato e acceso il Cannello) premete il pulsante Fiamma Continua. Per spegnere la fiamma continua premere di nuovo il Grilletto e rilasciarlo. **REGOLAZIONE DELLA FIAMMA:** Ruotate in senso antiorario la Manopola di Controllo del Gas per aumentare la potenza della fiamma e in senso orario per diminuirla. Ruotando completamente la Manopola di Controllo del Gas la fiamma si spegne. **RICARICA DEL GAS:** Disinserite il bottone Fiamma Continua e rilasciate il grilletto. Assicuratevi che la fiamma sia completamente spenta. Attendete finché il Cannello non sia completamente raffreddato prima di effettuare la ricarica. Ricaricate in ambiente ben ventilato, lontano da qualsiasi fiamma libera, da fumo e da eventuali rischi. La temperatura dell'ambiente deve essere attorno ai 16°C. Utilizzare solo gas butano pulito purificato al 100%. Evitare l'uso di gas butano che contiene molta impurità per bloccare la valvola di iniezione quando si utilizza con questo cannello. Girate il cannello sottosopra. Inserite l'ugello della bomboletta di Gas Butano nella valvola di ricarica. Riempite lentamente e smettete non appena il gas comincia a fuoriuscire. Aspettate almeno 3 minuti prima di usare il cannello per lasciare che il gas stabilizzi e che quello in eccesso evapori. Al primo utilizzo riempire completamente il serbatoio del gas, poi sfatare l'eventuale aria contenuta nel serbatoio. **IL RIEMPIMENTO ECCESSIVO PUÒ PROVOCARE FIAMMATE - ATTENZIONE: TENERE FUORI DALLA PORTATA DEI BAMBINI - CONTIENE LIQUIDO ALTAMENTE INFIAMMABILE SOTTO PRESSIONE** Non conservare a temperature superiori a 40°C (104°F) o esporre ai raggi solari. Non operare in ambienti chiusi in presenza di vapori combustibili, liquidi infiammabili o materiali esplosivi né vicino a scintille o fiamme libere; mantenere l'ambiente ventilato. Non forare né incendiare il Cannello. Montaggio e regolazioni di fabbrica non devono essere modificati. Potrebbe essere pericoloso tentare di modificare le regolazioni o la struttura del Cannello, smontarne i pezzi o usare componenti diversi da quelli raccomandati. Utilizzare il cannello con cura in modo che non venga danneggiato o rotto. Non tentare di riparare il Cannello o usarlo quando risulti danneggiato. In caso di fuga di gas, portare il Cannello in spazi aperti e ben ventilati lontano da scintille o fiamme libere fino a che il serbatoio non sia svuotato e restituire il Cannello al distributore. Indossare protezioni per gli occhi. **SEGUIRE RIGOROSAMENTE LE PROCEDURE DI RICARICA PER EVITARE SERI DANNI.** Nell'accendere il Cannello, tenerlo lontano dal volto, dagli indumenti e da materiali combustibili. Non rivolgere mai la fiamma verso le persone. Prestare attenzione all'illuminazione: in certe condizioni la fiamma di butano può essere scarsamente visibile. L'ugello del Cannello diventa rovente durante e dopo l'uso: è necessario proteggersi da scottature accidentali. Assicurarsi che la fiamma sia spenta dopo ogni utilizzo. Prima di riporre il Cannello lasciarlo raffreddare.



- 1) NOZZLE
- 2) TRIGGER
- 3) CONTINUOUS FLAME SWITCH
- 4) REFILLING VALVE (bottom of tank)
- 5) STAND
- 6) TANK
- 7) ON/OFF SWITCH
- 8) GAS CONTROL KNOB

- 1) BECCUCCIO
- 2) GRILLETTO
- 3) PULSANTE FIAMMA CONTINUA
- 4) VALVOLA DI RICARICA (sul fondo del serbatoio)
- 5) PIEDISTALLO
- 6) SERBATOIO
- 7) INTERRUOTTORE ON/OFF
- 8) MANOPOLA CONTROLLO DEL GAS