

USO DELL'AEROGRAFO A DOPPIA AZIONE

Riempire il serbatoio con colorante liquido specifico per aerografo.

Impugnare l'aerografo con delicatezza e posizionare l'indice sul pulsante, la pressione sul comando regola la quantità dell'aria in uscita, lo spostamento all'indietro regola la quantità di liquido spruzzato.

L'aeropenna è uno strumento che viene utilizzato per spruzzare il colore tramite aria compressa, per ottenere delle sfumature si consiglia di usare molta aria (premere a fondo il pulsante) e poco colore (tirare in modo delicato).

Diminuendo la pressione dell'aria e aumentando la quantità di colore si possono realizzare linee e dettagli.

Per capire il corretto funzionamento dell'aerografo si consiglia di esercitarsi su un foglio di carta, variando il flusso dell'aria, la quantità di colore e la distanza dal piano di lavoro.


MANUTENZIONE DELL'AEROGRAFO

Svuotare completamente il serbatoio e lavare con acqua o alcol etilico.


Per la pulizia degli organi interni riempire il serbatoio con acqua o alcol etilico, otturare l'aerografo mettendo un dito sull'ugello e premere il pulsante. L'aria, circolando in direzione inversa, pulisce gli elementi che si trovano fra l'ugello e il serbatoio ed elimina eventuali residui. Ripetete l'operazione più volte finché l'acqua non diventa limpida. Vaporizzare per alcuni secondi acqua o alcol su carta per controllare che l'aeropenna sia completamente pulita, se si dovessero presentare residui di colore ripetere l'intera operazione.

La pulizia è molto importante e deve essere eseguita alla perfezione al termine di ogni utilizzo.

SEZIONE AEROGRAFO



COMPONENTI AEROGRAFO



1	Copertura ago
2	Tappo ago
3	Ugello 0,3 mm
4	O-ring per ugello serbatoio
5	Ago
6	O-ring per guida ago
7	Guida ago
8	Coperchio serbatoio
9	Funzionamento della leva
10	Guida leva
11	Tappo
12	Ago guida serraggio
13	Molla
14	Custodia molla
15	Serraggio a rete per ago
16	Maniglia di regolazione
17	Vite di regolazione
18	Vite guida
19	O-ring leva della guida
20	O-ring valvola
21	Corpo valvola
22	O-ring valvola stelo
23	Valvola stelo
24	Valvole a molla
25	Valvola vite
26	Tubo dado del connettore
27	O-ring per portagomma
28	Portagomma
29	Chiave ugello
30	Serbatoio 7 CC

Prodotto importato da Martellato srl
via Rovigo, 1/B Vigonza (PD) Italy - tel. +39 049 7800155
www.martellato.com - martellato@martellato.com

HOW TO USE OUR DOUBLE ACTION AIRBRUSH

Fill the cup with specific liquid colour for airbrush.

Hold the airbrush gently and place your index on the button. The quantity of outgoing air depends on the pressure on the button; you determine how much liquid to spray by moving the button backward.

The airbrush is a tool used to spray colours by using compressed air. If you want to get some nuances we suggest to release a big quantity of air (by pushing the button) and little colour (by pulling gently). You will be able to realize lines and details by decreasing the air pressure and increasing the quantity of colour.

To understand how to use the airbrush we recommended to practice on a sheet of paper by varying the air flow, the quantity of colour and the distance from the working surface.


AIRBRUSH UPKEEPING

Empty the fluid cup and wash with water or ethyl alcohol.


To clean the internal parts fill the cup with water or ethyl alcohol, close the airbrush by putting a finger on the nozzle and press the button. Air will clean the elements that are placed between the nozzle and the cup and will remove any residual by circulating in the opposite direction. Repeat the process until the water becomes clear. Spray some water or alcohol on paper for a few seconds to make sure the airbrush is completely clean: if you find any residual colour repeat all the former steps.

Cleanliness is very important and must be perfectly performed after every use.

AIRBRUSH SECTION



AIRBRUSH COMPONENTS



1	Needle cover
2	Needle cap
3	Nozzle 0,3 mm
4	O-ring for nozzle cup
5	Needle
6	O-ring for needle guide
7	Needle guide
8	Lid for colour cup
9	Operation lever
10	Lever guide
11	Stopper
12	Needle chucking guide
13	Spring
14	Spring case
15	Needle chucking net
16	Standard-handle adjusting
17	Adjusting screw
18	Guide screw
19	Lever guide o-ring
20	Valve o-ring
21	Valve body
22	Valve rod o-ring
23	Valve rod
24	Valve spring
25	Valve screw
26	Hose connector nut
27	O-ring for hose connector
28	Hose connector
29	Nozzle spanner
30	Cup 7CC

Goods imported by Martellato srl
via Rovigo, 1/B Vigonza (PD) Italy - tel. +39 049 7800155
www.martellato.com - martellato@martellato.com